



1. Turn off general switch
2. Make holes apply plastic anchors
3. Apply screws with a screws driver
4. Connect the wires
5. Put it in place & apply side screws
6. Turn on general switch

