




1. Apply the bulb by rotate
2. Apply the cap into place by rotate
3. Plug it in power to turn it on/ off

